

**CSCI 4974 / 6974**  
**Hardware Reverse Engineering**

Lecture 12: Non-invasive attacks

# Quiz

- Memory technologies

# Attack types

- Non-invasive
  - Any attack which does not damage the package

# Non-invasive attacks

- Program/debug interfaces
- Power analysis
- Fault injection

# Program/debug interfaces

- Several common ones in use
  - JTAG
  - UART (serial port)
  - Vendor proprietary
- May give you anything from a shell on the chip to full code execution and firmware access!
- Usually locked down, but often not too strongly

# JTAG

- IEEE 1149.1 Joint Test Action Group
- Standard interface for IC test ports
- Standard only covers layer 2 and some of 3
  - Different connectors and voltage levels in use
  - A few basic registers defined in standard, others are up to the chip designer
- Can chain arbitrarily many devices end to end

# JTAG

- Full duplex interface with four pins total
  - One control pin (TMS)
  - Clock (TCK)
  - Shift register data in/out (TDI, TDO)
- Optional reset line (TRST)
- Nonstandard return clock (TRTCK)

# JTAG


- Two registers
  - IR = operation to perform
  - DR = data for that operation
- IR size is constant for any given chip
- DR is basically a pointer, target is set by IR
  - DR size varies with IR value



# JTAG

- JTAG TAP runs a simple state machine
- TMS controls state
  - Idle: nothing going on
  - Capture: store chip->host data in DR
  - Shift: move data in/out of DR
  - Update: process host->chip data

# JTAG



JTAG Test Access Port (TAP) controller state transition diagram

# Standard JTAG instructions

- BYPASS (IR = all 1s)
  - DR is a single D flipflop
- IDCODE (IR has this value at reset)
  - DR is a 32-bit unique identifier for device type
- EXTEST/SAMPLE/PRELOAD
  - IR value is chip-specific, defined in BSDL file
  - Used for boundary-scan board test

# Other JTAG instructions

- USERCODE (not required)
  - DR is a 32-bit value set by firmware
  - Used to check FW version etc
- Vendor-specific
  - Can be any size, any data format
  - May even be undocumented
  - Check BSDL and chip documentation

# Serial port (UART)

- Byte-wise 2-wire serial protocol
- Start bit, 8 data bits, stop bit
- Baud rates, connectors, etc vary
- Real RS-232 is +/- 12V levels on DE-9, most modern devices are LVCMOS33 on pin header
- Sometimes used for debug logging
- Many Linux devices have UART shells!

# Proprietary program/debug

- Read chip vendor datasheets for details
- Often locked down with read-protect bit
- When not disabled (or protection defeated), typically allows
  - dumping of firmware flash/SRAM
  - single-stepping CPU
  - reading/writing CPU registers
  - and more!

# Power analysis

- Short-term IC power consumption is a highly complex function depending on clock speed and actual data being processed
- Very difficult to predict exactly w/o process info
- But empirical data can be useful!

# Simple power analysis

- Look at graphs of power usage vs time
- Can typically distinguish
  - Sleep vs active instruction execution
  - Different types of CPU instruction (sometimes)
- Often enough for breaking sq+mult RSA



# Differential power analysis

- Use more complex statistical analysis
- Ex: cross-correlation between inst. with known inputs
- Look at high-frequency harmonics as signals propagate through combinatorial logic
- Can sometimes figure out actual data values in use

# Fault injection

- Cause circuit to malfunction in some way
- May or may not be precisely controllable
- Many different methods
  - Voltage
  - Temperature
  - Clock/timing
  - Radiation
  - Semi-invasive methods (see lecture 14)

# Fault injection

- Typically very low cost, minimal resources
- May require detailed circuit knowledge
- Common workflow:
  - Decap device, analyze circuit
  - Execute invasive attack
  - Determine exactly where to glitch
  - Non-invasive attack is more broadly usable

# Goals of fault injection

- Erase lock bits but keep FW flash intact
- Get CPU to skip an instruction
- Compute wrong value for cryptanalysis
  - See next lecture

# Thermal glitching

- Heat or cool chip beyond operating limits
- Hard to precisely control
  - Max  $dT/dt$  is limited by package thermal mass
  - Not used very often in practice for this reason

# Voltage glitching

- Drop power supply below minimum
- May corrupt SRAM contents
- Increases RC propagation delays
- Makes NVRAM erase/program unreliable
- Can be precisely targeted
  - One of the most common techniques

# Clock/timing glitching

- Send a clock pulse that's too short
  - Latch intermediate value or go metastable
- Can be precisely controlled
  - May be hard to predict exactly when to send glitch due to PTV variation
  - One of the most common techniques

# Radiation glitching

- Irradiate device with some kind of energy
  - X-rays
  - Gamma rays
  - Visible/UV/IR light (semi-invasive, needs decap)
  - Neutrons, alpha particles, etc
- Particles induce photocurrents, leakage, etc
- Aim beam to target portion of the die or even single transistors. Wavelength/tech dependent.



# Radiation glitching

- Some require minimal resources
  - Camera flash or laser pointer + microscope
  - Place device near piece of high-grade uranium ore and hope for the best!
- Focused beams of esoteric particles require serious equipment (particle accelerator etc)

# Data remanence

- Memory contents don't always disappear when “erased”!

# SRAM data remanence

- Charge stays on poly gates briefly after power is removed
- If device doesn't clear mem on reset, may be possible to read data after loading new FW etc

# DRAM data remanence

- Same phenomenon, increased capacitance means data can last longer
- Older DIMMs could even be pulled and moved to new mobo if chilled
- Modern processes leak more :(

# Flash data remanence

- FTL COW means old data may stick around
- Erase cycle moves most charge but not all
  - Voltage glitching may enhance this!
- Partial prog/erase may allow measuring residual charge

# Questions?

- TA: Andrew Zonenberg <azonenberg@drawersteak.com>
- Image credit: Some images CC-BY from:
  - John McMaster <JohnDMcMaster@gmail.com>

